

**Pumps**

<b>1 . START-UP INSTRUCTIONS &amp; RECOMMENDATIONS</b>	
1 . 1 . General & start-up check-up .....	3
1 . 2 . Shaft & coupling data .....	4
1 . 3 . Specific points .....	4
1 . 4 . Fluids .....	5
<b>2 . PUMP &amp; CARTRIDGE BREAKDOWN DRAWING .....</b>	<b>6</b>
<b>3 . CONVERSIONS</b>	
3 . 1 . Changing cartridge & shaft assembly	
Standard pump .....	7 to 13
3 . 2 . Changing cartridge - Drive train pump...	14 to 17
3 . 3 . Changing rotation .....	18 to 21
3 . 4 . Changing porting - Standard pump .....	22 to 23
3 . 5 . Changing porting - Drive train pump .....	24 to 26
3 . 6 . Changing adapter - Drive train pump .....	27 to 28
<b>4 . KEY SHEET, TORQUES &amp; PORTING TABLES</b>	
4 . 1 . Key sheet .....	29
4 . 2 . Porting tables .....	29
4 . 3 . Torque requirements .....	29
<b>5 . SPECIAL TOOLS</b>	
5 . 1 . Seal driver - Dimensions .....	30
5 . 2 . Protective cone - Dimensions .....	31
<b>6 . COUPLINGS</b>	
6 . 1 . Female coupling dimensions .....	32
<b>7 . VANE TROUBLESHOOTING GUIDE .....</b>	<b>33 to 36</b>
<b>NOTES .....</b>	<b>37 to 38</b>
<b>WARNING .....</b>	<b>39</b>

**1.1. GENERAL :**

All Parker vane pumps are individually tested to provide the best quality & reliability. Modifications, conversions & repairs can only be done by authorized dealers or OEM to avoid invalidation of the guarantee.

The pumps are to be used within the design limits indicated in all the sales bulletins. Please contact Parker when trespassing the catalogue limits.

Do not modify or work on the pump under pressure or when the electric motor (or any drive) is on.

Qualified personnel is required to assemble and set-up hydraulic devices.

Always conform yourself to the valid regulations (safety, electrical, environment...).

The following instructions are important to obtain a good service life time from the unit.

**ROTATION & PORTS INDICATION**

The rotation and ports orientation are viewed from the shaft end.

R = CW stands for clockwise = right-hand rotation.

L = CCW stands for counter-clockwise = left-hand rotation.

**START-UP & CHECK-UP**

**Check that the assembly of the power unit is correct :**

The distance between the suction pipe & the return lines in the tank should be at its maximum.

A bevel on both suction & return lines is recommended to increase the surface and so lower the velocity. We suggest a 45° minimum angle.

Velocities : inlet  $0,5 < x < 1,9$  m/s (1,64 < x < 6,23 ft per sec.)  
 : return  $x < 6$  m/s (x < 19,7 ft per sec.)  
 : Always insure that all return and suction lines are under the oil level to avoid forming aeration or vortex effect. This should be done under the most critical situation (all cylinders extended for example). Straight and short pipes are the best.

$$V = \frac{Q \text{ (Lpm)}}{6 \times p \times r^2 \text{ (cm)}} = \text{m/s} \quad V = \frac{Q \text{ (GPM)}}{3.12 \times p \times r^2 \text{ (in)}} = \text{ft/s}$$

The size of the air filter should be 3 times greater than the max. instant return flow (all cylinders in movement for example).

If the pump is in the tank, please choose the NOP option (no paint) and use a short inlet pipe.

Parker does not recommend inlet strainers. If needed, a 100 mesh (149 microns) is the finest mesh recommended.

A coaxial drive is recommended. For any other type of drives, please contact Parker.

Make sure that all protective plugs & covers have been removed.

Check the pump rotation versus the E-motor or engine rotation.

**Start-up :** The tank has been filled up with a clean fluid in proper conditions.

We recommend to flush the system with an external pump prior to the start-up.

It is important to bleed the air off the circuit and the pump itself.

first valve on the circuit should be open to tank.

We recommend the use of air bleed off valves.

It is possible to bleed off the air by creating a leak in the P port of the pump. **Warning : this has to be done in a low pressure mode as it could create a dangerous fluid leak. Make sure that the pressure cannot rise (open center valve to tank, pressure relief valve unloaded ...).**

When oil-free of air appears, tighten the connectors to the correct torque.

The pump should prime within a few seconds. If not, please consult our troubleshooting guide (page 33).

If the pump is noisy, please troubleshoot the system.

Never operate the pump at top speed and pressure without checking the completion of pump priming.

**1.2. SHAFT & COUPLING DATA :  
COUPLINGS AND FEMALE SPLINES**

- The mating female spline should be free to float and find its own center. If both members are rigidly supported, they must be aligned within 0,15 TIR (0.006" TIR) or less to reduce fretting. The angular alignment of two splines axes must be less than ± 0,05 per 25,4 radius (± 0.002" per 1" radius).
- The coupling spline must be lubricated with a lithium molydisulfide grease, disulfide of molybdenum or a similar lubricant.
- The coupling must be hardened to a hardness between 29 and 45 HRC.
- The female spline must be made to conform to the Class 1 fit as described in SAE-J498b (1971). This is described as a Flat Root Side Fit.

**KEYED SHAFTS**

Parker supplies the T7 series keyed shaft pumps with high strength heat-treated keys. Therefore, when installing or replacing these pumps, the heat-treated keys must be used in order to ensure maximum life in the application. If the key is replaced, it must be a heat-treated key between 27 and 34 R.C. hardness. The corners of the keys must be chamfered by 0,76 mm to 1,02 mm (0.03 to 0.04) at 45° to clear the radii in the key way.

The alignment of keyed shafts must be within tolerances given for splined shafts here above.

**SHAFT LOADS**

These products are primarily designed for coaxial drives which do not impose axial or side loading on the shaft. Contact Parker for specific applications.

**1.3. SPECIFIC POINTS :  
MINIMUM INLET PRESSURE**

Please read the charts in the sales leaflets as the minimum requested inlet pressure varies versus the displacement and the speed. Never go under 0,8 bar Absolute (-0,2 bar relative)  
11.6 PSI Absolute (-2.9 PSI G).

**MAXIMUM INLET PRESSURE**

It is recommended to always have at least 1,5 bar (22 PSI) differential between inlet and outlet. Standard shaft seals are limited to 0,7 bar (10 PSI G) but some allow 7 bar (100 PSI G). Please contact Parker for more information.

**MINIMUM OUTLET PRESSURE**

It is recommended to always have at least 1,5 bar (22 PSI) differential between inlet and outlet.

**VERTICAL MOUNT**

When assembled vertically, always be careful to prevent any air from being trapped in the pump (behind the shaft seal for example).

**Vane**

**1.4. FLUIDS :**

**DENISON CLASSIFICATION**

Type of fluids : For each type of fluids, Parker vane pumps will products have different pressures, speeds & temperature limits. Please refer to the sales leaflets.

- HF-0 = Anti-wear petroleum base.
- HF-1 = Non anti-wear petroleum base.
- HF-2 = Anti-wear petroleum base.
- HF-3 = Water-in-oil invert emulsions.
- HF-4 = Water glycol solutions.
- HF-5 = Synthetic fluids.

**FILTRATION RECOMMENDATIONS**

NAS 1638 class 8 or better.  
ISO 19/17/14 or better.

Inlet strainers : Parker does not recommend inlet strainers.

If requested, a 100 mesh (149 microns) is the finest mesh recommended.

**RECOMMENDED FLUIDS**

Petroleum based antiwear R & O fluids.

These fluids are the recommended fluids for pumps & motors. Maximum catalogue ratings and performance datas are based on operation with these fluids. These fluids are covered by Parker Denison HF-0 and HF-2 specifications.

**ACCEPTABLE ALTERNATE FLUIDS**

The use of fluids other than petroleum based antiwear R & O fluids requires that the maximum ratings of the pumps will be reduced. In some cases the minimum replenishment pressures must be increased. Consult specific sections for more details (page 4).

**VISCOSITY**

	Mobile	Industrial
Max. (cold start, low speed & pressure)	2000 cSt - 9400 SUS	860 cSt - 3900 SUS
Max. (full speed & pressure)	108 cSt - 500 SUS	108 cSt - 500 SUS
Optimum (max. life)	30 cSt - 140 SUS	30 cSt - 140 SUS
Min. (full speed & pressure for HF-1, HF-3, HF-4 & HF-5 fluids)	18 cSt - 90 SUS	18 cSt - 90 SUS
Min. (full speed & pressure for HF-0 & HF-2 fluids)	10 cSt - 60 SUS	10 cSt - 60 SUS

**VISCOSITY INDEX**

90 min. Higher values extend the range of operating temperatures.

**TEMPERATURE**

The usual limiting factor of temperature (low or high) comes from the obtained viscosity. The seals are sometimes the limit : standard seals range from -30° C to 90° C (-9.4° F to 194° F).

Maximum fluid temperature (θ)	° C	° F
HF-0, HF-1, HF-2	+ 100	+ 212
HF-3, HF-4	+ 50	+ 122
HF-5	+ 70	+ 158
Biodegradable fluids (esters & rapeseed base)	+ 65	+ 149
Minimum fluid temperature (θ) (also depend on max. viscosity)	° C	° F
HF-0, HF-1, HF-2, HF-5	- 18	- 0.4
HF-3, HF-4	+ 10	+ 50
Biodegradable fluids (esters & rapeseed base)	- 18	- 0.4



Over or under these values, please contact Parker.

**WATER CONTAMINATION IN THE FLUID**

Maximum acceptable content of water :


- 0,10 % for mineral base fluids.
  - 0,05 % for synthetic fluids, crankcase oils, biodegradable fluids.
- If the amount of water is higher, then it must be drained off the circuit.

Pumps




**3.1. CHANGING CARTRIDGE & SHAFT ASSEMBLY - STANDARD PUMP :**

1 . Install the pump on the table.




Two bolts will help to unscrew the 4 pumps bolts.

2 . Unbolt the 4 screws.




**3.1 . CHANGING CARTRIDGE & SHAFT ASSEMBLY - STANDARD PUMP :**

3 . Remove the housing.




4 . Disassemble the cartridge / front cap with an extractor.





**3.1. CHANGING CARTRIDGE & SHAFT ASSEMBLY - STANDARD PUMP :**



If you wish to convert the cartridge, go to page 18.

A : Remove the retaining ring.


B : Extract the shaft / bearing assembly.



Take a protection cone to prevent seal damage (dim. page 31).  
 If you don't, change the shaft seal.


If not new, the shaft seal should be replaced.

If the shaft  $\varnothing$  is bigger than the shaft seal  $\varnothing$ , please contact Parker (TPI).



**3.1. CHANGING CARTRIDGE & SHAFT ASSEMBLY - STANDARD PUMP :**

5. Install the shaft seal (special tool dimensions, page 30).




Press carefully to avoid damaging the seal.

6. Install the shaft assembly.

A : Protective cone on the shaft assembly (dim. per shaft in page 31).

B : Shaft assembly + protective cone into the front cap. Slightly rotate the shaft to avoid the shaft seal lip(s) to be deteriorated.

C : Retaining ring into the front cap.



To avoid damaging the shaft seal, do not forget to put a protective cone on the shaft (dim. page 31).




Push on the external bearing "cage".




If the shaft  $\varnothing$  is bigger than the shaft seal  $\varnothing$ , please contact Parker (TPI).

**3.1. CHANGING CARTRIDGE & SHAFT ASSEMBLY - STANDARD PUMP :**

7 . Fit the cartridge into the housing.



8 . Check if the dowel pin is in its position in the housing by trying to rotate the cartridge.




Put some grease on the seals to prevent them from moving.

If the cartridge does rotate, the dowel pin is not in the hole. Take the cartridge out and try again.


**3.1 . CHANGING CARTRIDGE & SHAFT ASSEMBLY - STANDARD PUMP :**

If the cartridge does not fit in the housing correctly, check the concentricity of the three elements = port plates (rear & pressure) & cam ring (see page 21).

9 . Assemble the front cap assy on the housing & cartridge assy.



Never use a hammer. The cartridge is to fit into the housing without any tools.




Position the shaft / front cap assy only if the cartridge is well positioned, dowel pin in the housing dowel pin hole.


Put some grease on the seals to prevent them from moving.

3.1. CHANGING CARTRIDGE & SHAFT ASSEMBLY - STANDARD PUMP :

10. Final assy.



- a) Always check if the shaft rotates. (a slight torque due to the spring loaded resistance force). Otherwise, please go back to the previous step.
- b) Flip / rotate the pump to fit the 4 screws.
- c) Fix the pump to the table (as page 7) before tightening the pump's bolts.
- d) Check the porting configuration (see table page 29).
- e) Tighten the 4 screws.



Step by step to avoid damaging the seals.


TORQUE REQUIREMENTS :

Pump	Nm	ft.lbs
T6C - T6CM - T6CP	159	117
T6D - T7D	187	138
T6E - T7E	187	138
T7B - T7BS	187	138


- f) Always check if the shaft rotates. If not, disassemble and go back to the previous step.

3.2. CHANGING CARTRIDGE - DRIVE TRAIN PUMP : Pumps

1 . Remove the coupling




2 . Install the pump on the table.




**3.2. CHANGING CARTRIDGE - DRIVE TRAIN PUMP: Vane Pumps**

3 . Unbolt the 4 screws.




4 . Remove the front cap/  
cartridge assembly.




**3.2 . CHANGING CARTRIDGE - DRIVE TRAIN PUMP : Pumps**

5 . Disassemble the cartridge from the front cap with an extractor.



6 . All needed sub-assemblies are obtained.




For shaft modification,  
see page 9.  
For cartridge modification,  
see page 18.  
For reassembly, see next  
page.




**3.2 . CHANGING CARTRIDGE - DRIVE TRAIN PUMP : Vane Pumps**

7 . Assemble the new cartridge in the housing.



Check if the dowel pin is in its position in the housing by trying to rotate the cartridge.


8 . Install the front cap & shaft assembly. Orient the P1 to obtain the correct porting (see page 29).



a) Always check if the shaft rotates . (a slight torque due to the spring loaded resistance force). Otherwise, please go back to the previous step.

b) Check the porting configuration (see table page 29).

c) Tighten the 4 screws.



Step by step to avoid damaging the seals.

d) Always check if the shaft rotates. If not, disassemble and go back to the previous step.

**TORQUE REQUIREMENTS :**

Pump	Nm	ft.lbs
T6C - T6CM - T6CP	159	117
T6D - T7D	187	138
T6E - T7E	187	138
T7B - T7BS	187	138


**3.3. CHANGING ROTATION :**

**Pumps**


1. Explanations :

Bi & uni-rotational port plates.


**Bi-rotational port plate**




**Uni-rotational port plate**



**Bi-rotational port plate**



**Uni-rotational port plate**




**3.3 . CHANGING ROTATION :**




It is possible to change the rotation if the port plates are bi-rotational.

If uni-rotational, change the port plates to change the rotation.

2 . Remove the two retaining screws.



3 . Remove the rear port plate.



Rear port plate with or without bushing, it depends :  
P2 position = no bushing.  
P3 position = with bushing.



Same parts could sticks to the port plate.

3.3. CHANGING ROTATION :


Pumps

4 . Take the cam ring out,  
flip it around the hori-  
zontal axis.

Push all the vanes inside  
the rotor to avoid any da-  
mage of it.

5 . Change the dowel pin  
from A to B.


Position the cam ring.



**3.3 . CHANGING ROTATION :**

6 . Position the dowel pin.

7 . Position the port plate & screws.



Before tightening the screws, rotate the rotor/vane.

Retaining screws = assembly purpose & concentricity of the elements.


Rotate rotor after cartridge assembly.

The screws should only be loosely tightened.

Try to assemble all the elements as cylindrically as possible.

**GOOD  
CONCENTRICITY**


**BAD  
CONCENTRICITY**



If the elements are not properly assembled together (bad concentricity), the cartridge will not fit correctly into the housing.

3.4. CHANGING PORTING - STANDARD PUMP : Pumps

1 . Install the pump on the table.




Two bolts will help to unscrew the 4 pump bolts.

2 . Unscrew the 4 bolts.

3 . Keep two bolts.

4 . Rotate the housing with a bar blocked between the two screws.



Rotate


Do not lift the housing, this to prevent the dowel pin from leaving its position in the housing.

Note : the cartridge will rotate with the housing.

**3.4. CHANGING PORTING - STANDARD PUMP :**

5 . Put the screws back.


6 . Tighten to the correct torque (see table hereunder).



a) Always check if the shaft rotates. (a slight torque due to the spring loaded resistance force). Otherwise, please go back to the previous step.

b) Check the porting configuration (see table page 29).

c) Tighten the 4 screws.



Step by step to avoid damaging the seals.


**TORQUE REQUIREMENTS :**

Pump	Nm	ft.lbs
T6C - T6CM - T6CP	159	117
T6D - T7D	187	138
T6E - T7E	187	138
T7B - T7BS	187	138


d) Always check if the shaft rotates. If not, disassemble and go back to the previous step.

**3.5 . CHANGING PORTING - DRIVE TRAIN PUMP : Pumps**

1 . Remove the coupling.



2 . Install the pump on the table.




Two bolts will help to unscrew the 4 pump bolts.



3.5. CHANGING PORTING - DRIVE TRAIN PUMP : Pumps


3 . Unbolt the 4 screws.



4 . Keep two bolts.


5 . Rotate the front cap with a bar blocked between the two screws.

2 bolts in front flange to rotate "P1".



Do not lift the cap end, this to prevent the dowel pin from leaving its position in the housing.


**3.5 . CHANGING PORTINGS - DRIVE TRAIN PUMP : Pumps**



a) Always check if the shaft rotates. (a slight torque due to the spring loaded resistance force). Otherwise, please go back to the previous step.

b) Check the porting configuration (see table page 29).

c) Tighten the 4 screws.



Step by step to avoid damaging the seals.


**TORQUE REQUIREMENTS :**

Pump	Nm	ft.lbs
T6C - T6CM - T6CP	159	117
T6D - T7D	187	138
T6E - T7E	187	138
T7B - T7BS	187	138

d) Always check if the shaft rotates. If not, disassemble and go back to the previous step.


3.6. CHANGING ADAPTER - DRIVE TRAIN PUMP: Pumps

1 . Install the pump on the table.



2 . Unbolt the 4 screws.

3 . Remove the adapter.



3.6. CHANGING ADAPTER - DRIVE TRAIN PUMP : Pumps Vane


COUPLINGS :

	SAE A - 9 teeth	SAE B		SAE BB	SAE C	SAE 11 teeth
		For adapter SAE B	For adapter SAE A			
T6CR	034 - 66537 - 0	034 - 66540 - 0	034 - 66649 - 0	034 - 66543 - 0	034 - 66546 - 0	034 - 66652 - 0
T6DR - T7DRS	034 - 66538 - 0	034 - 66541 - 0	034 - 66650 - 0	034 - 66544 - 0	034 - 66547 - 0	034 - 66653 - 0
T6ER - T7ERS	034 - 66539 - 0	034 - 66542 - 0	034 - 66651 - 0	034 - 66545 - 0	034 - 66548 - 0	034 - 66654 - 0

ADAPTERS :

	SAE A	SAE B	SAE C
T6CR	034 - 67437 - 0	034 - 67438 - 0	034 - 66934 - 0
T6DR - T7DRS			
T6ER - T7ERS			


4 . Assemble the new adapter & new couplings.



a) Always check if the shaft rotates. (a slight torque due to the spring loaded resistance force). Otherwise, please go back to the previous step.

b) Check the porting configuration (see table page 29).

c) Tighten the 4 screws.



Step by step to avoid damaging the seals.

d) Always check if the shaft rotates. If not, disassemble and go back to the previous step.

TORQUE REQUIREMENTS :

Pump	Nm	ft.lbs
T6CR	72	53
T6DR - T7DRS		
T6ER - T7ERS		

**4.1. KEY SHEET :**

**Drive train option**

**Model No.** T6C R - 022 - 1 R 00 - A 1 0 - A 1 - ..

**Series - SAE B 2 bolts** J744 mounting flange

**Drive train** \_\_\_\_\_

**Displacement P1** \_\_\_\_\_  
 Volumetric displacement (ml/rev.)  
 003 = 10,8      017 = 58,3  
 005 = 17,2      020 = 63,8  
 006 = 21,3      022 = 70,3  
 008 = 26,4      025 = 79,3  
 010 = 34,1      028 = 88,8  
 012 = 37,1      031 = 100,0  
 014 = 46,0

**Type of shaft** \_\_\_\_\_  
 1 = keyed (SAE B) Ø 22,2  
 2 = keyed (non SAE)  
 3 = splined (SAE B) 13 teeth  
 4 = splined (SAE BB) 15 teeth

**Direction of rotation (shaft end view)** \_\_\_\_\_  
 R = Clockwise  
 L = Counter-clockwise

**Modifications**

**Seal class**  
 1 = S1 BUNA N - 0,7 bar max. (for mineral oil)  
 4 = S4 EPDM - 7 bar max. (for fire resistant fluids)  
 5 = S5 VITON® - 7 bar max. (for mineral oil and fire resistant fluids)

**Design letter**

**Porting adapter**

**Coupling**  
 1 = SAE A      4 = SAE C  
 2 = SAE B      5 = SAE J498b  
 3 = SAE BB      16/32 - 11 teeth

**Adapter**  
 0 = None      B = SAE B  
 A = SAE A      C = SAE C

**Porting combination**  
 00 = standard

**4.2. PORTING TABLES :**

**Porting adapter**

P = Pressure port  
 S = Suction port


**4.3. TORQUE REQUIREMENTS :**

	T7B	T6C T6CR	T6D / T7D T6DR / T7DRS	T6E / T7E T6ER / T6ERS
<b>Torque on the 4 main bolts (front cap / housing)</b>	187 Nm 138 ft.lbs	159 Nm 117 ft.lbs	187 Nm 138 ft.lbs	187 Nm 138 ft.lbs
<b>Drive train only</b>				
<b>Torque on the adapter (adapter / housing) 4 bolts</b>		72 Nm 53 ft.lbs	72 Nm 53 ft.lbs	72 Nm 53 ft.lbs
<b>Torque between the adapter and the adapted pump (2 screws)</b>		SAE A = 49 Nm      36 ft.lbs SAE B = 88 Nm      65 ft.lbs SAE C = 190 Nm     140 ft.lbs		

5.1. SEAL DRIVER - DIMENSIONS :

Pumps

Series	Tool n°	Ø A		Ø B		C	
		mm	inch	mm	inch	mm	inch
T6C - T6CM - T6CP	DM3-418S0-1	25,27	0.995	37,82	1.489	145	5.708
		25,40	1.000	37,98	1.495		
T6D - T7D	DM3-418S0-2	34,74	1.368	56,92	2.241	145	5.708
		34,90	1.374	57,11	2.248		
T6E - T7E	DM3-418S0-4	41,11	1.618	59,97	2.361	145	5.708
		41,27	1.625	60,16	2.368		
T7B - T7BS	DM3-418S1-0	31,60	1.244	44,16	1.738	145	5.708
		31,75	1.250	44,32	1.745		
T6CR	DM3-418S1-0	31,60	1.244	44,16	1.738	145	5.708
		31,75	1.250	44,32	1.745		
T6DR - T7DRS	DM3-418S0-4	41,11	1.618	59,97	2.361	145	5.708
		41,27	1.625	60,16	2.368		
T6ER - T7ERS	DM3-418S0-4	41,11	1.618	59,97	2.361	145	5.708
		41,27	1.625	60,16	2.368		




Notes :

- 1 . Remove all burrs and break sharp edges :  
0,25/0,13 R (.010/.005 R).
- 2 . Length  $\triangle 2$  to be heat treated to 47 + 3 HRC.
- 3 . Length  $\triangle 2$  to have a  $10-20$  full length, with a smooth intersection between chamfer and dia "A".
- 4 . Grease O.D. of length  $\triangle 2$  before installing the shaft seal on the tool to avoid damaging the seal.  
Material US 4140 / UK 708 M40 or equivalent.

5.2. PROTECTIVE CONE - DIMENSIONS :

Series	Code n°	Tool n°	A		Ø B		Ø C	
			mm	inch	mm	inch	mm	inch
T6C*	1 & 2	DM3-392CP-01	70,0	2.756	25.30	0.996	22.28	0.877
	3	DM3-392CP-33	38,0	1.496	25.40	1.000	22.35	0.880
T6CP	3	DM3-392CP-14	60,0	2.362	34,95	1.376	21.86	0.859
	2	DM3-392CP-02	83,0	3.268	35,00	1.378	21.81	0.861
T6D T7D	1 & 2	DM3-392CP-02	83,0	3.268	34,95	1.376	31.25	1.230
	3	DM3-392CP-14	60,0	2.362	35,00	1.378	31.33	1.233
4	31.80		1.252					
T6E T7E	1	DM3-392CP-04	89,0	3.504	41,25 41,33	1.624 1.627	31.88	1.255
	2	DM3-392CP-11	80,0	3.150			31.25	1.230
	3	DM3-392CP-24	93,0	3.661			31.33	1.233
	3	DM3-392CP-10	55,0	2.165			31.80	1.252
T7B / T7BS	2	DM3-392CP-19	68,0	2.677	31,77 31,72	1.251 1.249	31.88	1.255
	4						25,03	0.985
	3	DM3-392CP-17	36,0	1.417			25,13	0.989
	1	DM3-392CP-05	70,0	2.756			21,85	0.860
T6CR	1	DM3-392CP-15	70,0	2.756	31,77 31,72	1.251 1.249	21,93	0.863
	2	DM3-392CP-05	70,0	2.756			22,28	0.877
	3	DM3-392CP-17	36,0	1.417			22,35	0.880
	4	DM3-392CP-19	68,0	2.677			21,85	0.860
T6DR T7DRS	1	DM3-392CP-11	80,0	3.150	41,25 41,33	1.624 1.627	21,93	0.863
	2	DM3-392CP-04	89,0	3.504			25,03	0.985
	3	DM3-392CP-10	55,0	2.165			25,13	0.989
	5	DM3-392CP-16	80,0	3.150			31,25	1.230
T6ER T7ERS	1	DM3-392CP-04	89,0	3.504	41,25 41,33	1.624 1.627	31,33	1.233
	3	DM3-392CP-10	55,0	2.165			31,25	1.230
	4	DM3-392CP-18	56,0	2.205			31,33	1.233
							37,62	1.481
							37,70	1.484



full length of O.D. no tool marks or scratches permissible with a smooth intersection between 10° chamfer & dia. "B".

Notes :


1. Remove all burrs and break sharp edges : 0.25/0.13 R (.010/.005 R).
2. Teflon preferred, alternate 4140 treated after machining to RC 50-55.
3. Install protective cone over shaft extension and grease O.D. to prevent damaging the shaft seal.



If shaft Ø > than shaft seal Ø, there are not specific tools. Please contact Parker for the specific TPI.


**6.1. FEMALE COUPLING DIMENSIONS :**  
**SPLINED SHAFTS :**

**Pumps**



Shafts	T7BS code 3 T6C* code 3		T7BS code 4 T6C* code 4		T6CP code 3 T6D* - T7DS code 3 & 4 T6E* - T7ES code 3		T6E* - T7ES code 4	
	SAE B		SAE BB		SAE C		SAE CC	
Number of teeth	13		15		14		17	
Pitch	16/32		16/32		12/24		12/24	
	mm	inch	mm	inch	mm	inch	mm	inch
Major dia.	22,221	0.8748	25,400	1.0000	31,750	1.2500	38,100	1.5000
	22,500	0.8858	25,679	1.0110	32,080	1.2630	38,430	1.5130
Minor dia.	19,134	0.7533	22,268	0.8767	27,589	1.0862	33,876	1.3337
	19,261	0.7583	22,395	0.8817	27,716	1.0912	34,003	1.3387
Pitch dia.	20,638	0.8125	23,812	0.9375	29,634	1.1667	35,984	1.4167
Form dia.	21,908	0.8625	25,082	0.9875	31,326	1.2333	37,676	1.4833
Pin dia.	2,743	0.1080	2,743	0.1080	3,658	0.1440	3,658	0.1440
Max. measurement between two pins	16,505	0.6498	19,722	0.7765	24,305	0.9569	30,562	1.2032
	16,589	0.6531	19,807	0.7798	24,407	0.9609	30,648	1.2066
Circular space width :								
Min. effective	2,494	0.0982	2,494	0.0982	3,325	0.1309	3,325	0.1309
Max. actual	2,560	0.1008	2,560	0.1008	3,398	0.1338	3,401	0.1339
Radius max.	0,150	0.0059	0,150	0.0059	0,300	0.0118	0,300	0.0118

**KEYED SHAFTS :**



Shafts	T6C code 1 & 2 T7BS code 1		T6CP code 2 T6D* - T7DS code 1 - 2 T6E* - T7ES code 2		T6E* - T7ES code 1		T7B/T7BS code 2		T7D/T7DS code 5		T6E/T7ES code 5	
	mm	inch	mm	inch	mm	inch	mm	inch	mm	inch	mm	inch
Diameter	22,232	0.8753	31,759	1.2504	38,109	1.5004	25,007	0.984	32,025	1.2608	38,025	1.497
	22,253	0.8761	31,784	1.2513	38,134	1.5013	25,028	0.985	32,050	1.2618	38,050	1.498
W	6,363	0.2505	7,953	0.3131	9,533	0.3753	7,982	0.314	9,982	0.393	9,982	0.393
	6,414	0.2525	8,004	0.3151	9,584	0.3773	8,018	0.316	10,018	0.394	10,018	0.394
B	24,970	0.9831	35,212	1.3863	42,250	1.6634	28,30	1.114	35,30	1.390	41,30	1.626
	25,098	0.9881	35,339	1.3913	42,377	1.6684	28,40	1.118	35,40	1.394	41,40	1.630



**7 . VANE TROUBLESHOOTING GUIDE :**

**Pumps**

<p>1 . No flow, no pressure</p>	<p>a) Is the pump rotating ?</p> <p>b) Is the rotation in the correct direction?</p> <p>c) Is the air bleed-off done?</p> <p>d) How are the inlet conditions?</p> <p>e) Is the Viscosity not too high?</p> <p>f) Is the pump flow not going somewhere else?</p> <p>g) Is the receptor working correctly?</p> <p>h) Is the speed high enough?</p>	<p>a-1) Check if the coupling is rotating. If not, check the rotation of the electric motor. a-2) Check the keys of the pump and E motor shaft. a-3) Check if the shaft is not broken.</p> <p>b-1) Check if the rotation of the pump corresponds to the arrow on the name plate. b-2) Check if the wiring of the electric motor is correct.</p> <p>c-1) Check that no air is still located in the pressure line. Loosen a connector.</p> <p>d-1) Check if the inlet gate valve is not closed. d-2) Check the oil level. d-3) Check if the inlet hose in the tank is under the oil tank level. d-4) Check if an air intake is not disturbing the inlet (missing inlet flange seal, air trapped in suction line as examples). d-5) Check if the pump is not located too high above the oil level. d-6) Check if the tank is not completely sealed. Then the lack of atmospheric pressure will not allow the pump to prime. d-7) Check if all connections and seals are air-tight.</p> <p>e-1) Check if the oil characteristics are not incompatible with the temperature and the pumps requirements. Too high Viscosity will "stick" the vein fluid and enable the pump to suck the oil correctly.</p> <p>f-1) Check the hydraulic circuit and the main sequences. Doing so, you will check if all the valves are set or work properly. f-2) Check if the main relief valve is not set at an extremely low pressure and therefore bringing all the flow back to the tank. f-3) Check if in the directional valves the spools are not sticking in a position that brings the flow back to the tank. f-4) check if the check valve is not mounted «upside down».</p> <p>g-1) Check if the motor does not let all the flow leak internally. g-2) Check if the cylinder inner seals are not ruined.</p> <p>h-1) Check if the minimum speed is reached. Mobile pumps require 400 rpm and industrial pumps require 600 rpm.</p>
<p>2 . Not enough flow (or not the flow required)</p>	<p>a) Are the components OK?</p>	<p>a-1) Check the displacement of the pump. a-2) Check if the speed of the pump is not too low or too high (E motor or thermic engine sized too small so dropping the speed too low...). a-3) Check if the main relief valve is not set at an extremely low pressure and therefore venting some flow back to the tank.</p>

**7 . VANE TROUBLESHOOTING GUIDE :**

**Pumps**

<p>2 . Not enough flow (or not the flow required) (continuation)</p>	<p>a) Are the components OK ? (continuation)</p> <p>b) Is the connection from the tank to the pump correct ?</p> <p>c) Is the tank design correct ?</p> <p>d) Is the oil convenient ?</p>	<p>a-4) Check if in the directional valves the spools are not sticking in a position that brings part of the flow back to the tank.                      a-5) Check if the hydraulic motor is not leaking internally due to a bad efficiency, low viscosity...                      a-6) Check if the cylinder inner seals are not ruined and therefore allow internal leakage.</p> <p>b-1) Check if there is no air intake between the pump and the inlet pipe (bad seals for example).                      b-2) Check if the inlet hose is convenient for the required velocity (<math>0,5 &lt; V &lt; 1,9</math> m/s).                      b-3) Check if the pump is not too high compared to the oil level or if the pump is not too far from the tank (check the inlet absolute pressure with the catalog values).                      b-4) Check if the gate valve is not semi-open.                      b-5) Check if the inlet strainer is sized correctly (250 m mesh mini.) or not clogged.</p> <p>c-1) Check if the oil level is correct.                      c-2) Check if the suction pipe is under the oil level during the complete cycle of the machine.                      c-3) Check if the inlet hose fitted in the tank is cut with an angle wider than <math>45^\circ</math>.                      c-4) Check if this inlet hose is not too close to the tank wall or to the bottom of the tank and therefore limits the "vein flow".                      c-5) Check if the suction hose is not located near the return line and therefore sucking a lot of air coming from these turbulences.                      c-6) Check if baffles are required to allow correct deareation of the fluid.                      c-7) Check if the air filter is not clogged or undersized (not well dimensioned).                      c-8) Check if the tank is not fully tight, not allowing the atmospheric pressure to apply.</p> <p>d-1) Check if the oil characteristics are not incompatible with the pumps requirements.                      d-2) Check if the viscosity is not too high, therefore «sticking» some vanes in the rotor or blocking the vein fluid.                      d-3) Check if the high temperature does not destroy the viscosity of the fluid. Doing so, the internal leakage will «consume» the flow.</p>
<p>3 . No pressure</p>	<p>a) Is the hydraulic circuit correctly designed ?</p> <p>b) Is the circuit correctly piped ?</p>	<p>a-1) Check the hydraulic circuit schematic.</p> <p>b-1) Compare the schematic to the piped circuit.</p>



**7 . VANE TROUBLESHOOTING GUIDE :**

**Pumps**

<p>6 . Unusual heat level</p>	<p>a) Does the heat appear when the pump is running without pressure?</p> <p>b) Does the heat appear when the pump is running with pressure?</p>	<p>a-1) Check the oil level and the suction pipe. Is the oil coming to the pump (check the length of the pipe, its internal diameter, all that could influence the inlet pressure)?</p> <p>a-2) Check if the air bleed has been done correctly.</p> <p>a-3) Check if the flow versus the volume of oil in the tank is correct to obtain a good cooling effect.</p> <p>a-4) Check if a cooler is required or, if there is one, if it is well dimensioned.</p> <p>a-5) If there is a cooler, check if it is working (example for water cooler: is the water flow open or sufficient).</p> <p>a-6) Check if the hydraulic circuit is not bringing back the flow directly to the inlet port. Doing so, it would create a very small closed circuit not able to cool down the fluid.</p> <p>a-7) Check the quality of the fluid.</p> <p>a-8) Check the velocity of the fluid.</p> <p>a-9) Check the filtration unit, its capacity and if the heat does not come from the open by-pass valve or if it is under-dimensioned (bigger delta P).</p> <p>b-1) Check the viscosity.</p> <p>b-2) Check the pressure rating.</p> <p>b-3) Check if the cooler is working correctly or well dimensioned.</p> <p>b-4) Check if the relief valve is not creating this heat because always open.</p> <p>b-5) Check if any other component in the system is not creating this heat due to an internal defect.</p> <p>b-6) Check if there is a big temperature differential between the inlet and the outlet.</p>
<p>7 . Shaft seal leakage</p>	<p>a) Is the seal destroyed?</p> <p>b) Is the seal only leaking?</p>	<p>a-1) Check the alignment and the correct power transmission (non homokinetic movement, high radial force as examples).</p> <p>a-2) Check the inlet pressure and compare it to the catalog values.</p> <p>a-3) Check if the bad suction conditions do not create a vacuum that could even reverse the seal lip.</p> <p>a-4) Check if the external environment is not too dirty and therefore ruining the seal.</p> <p>b-1) Check the alignment of the front shaft and check if there is not any radial load.</p> <p>b-2) Check if seal lip has not been cut during a maintenance operation.</p> <p>b-3) Check if the inlet pressure is not over or under the catalog values. This has to be done for the whole cycle because the inlet pressure can vary from time to time.</p> <p>b-4) Check if the seal material has not been modified because of a too warm environment. The seal can vulcanize and stop sealing correctly.</p> <p>b-5) Check the acidity of the oil that can «burn» the seals material. It will therefore destroy the elasticity of the sealing.</p> <p>b-6) Check if the chosen seal (high pressure seal for example) is not too stiff for the use. If the environment requires some elasticity due to a gentle misalignment, a high pressure seal will not be able to follow the movement and therefore leak.</p>